Fluxio Online

V1.0. okt 2019

NL > Montage handleiding, Assa Abloy EL voorplaat

-Draai met een Torx T20 schroevendraaier of bit de voorplaat los van het Assa Abloy EL slot.
-Verwijder de voorplaat voorzichtig en schuif de nieuwe over de schoten heen.
-Positioneer de schoten zo dat de voorplaat er overheen vallen.
-Schroef 1 voor 1 de Torx 20 vast.
-Probeer handmatig de schoten uit te werpen om te controleren of het functioneert
-Beste is bij het aandraaien van de eerste schroef deze functie gelijk te controleren.
-Past niet op smalstoten pc92 alleen PC72 doornmaat 55/60/65

EN > Assembly manual, replacement frond plate

-Loosen the front plate screws with a Torx T20 screwdriver or bit of the Assa Abloy EL type lock.
-Carefully remove the front plate and slide the new one over the shots.
-Position the shots so that the face plate falls over them.
-Fasten the Screws Torx 20 one by one.
-Try to manually eject the latch and trigger bolts to check if it works.
-Its best to check this function immediately when tightening the first screw.
-Fits only on backset size 55/60/65 PC72 locks

